## **Basin heaters**

Spare parts guide

## **Basin heaters**

- Our factory-installed heaters keep the water temperature at 4°C and act as a simple and economical **anti-freeze measure for the basin water**.
- The heater package includes the **heaters**, a **thermostat** and a **low level cut out switch** to protect the heaters if the water level declines excessively.
- Standard electric heaters can handle ambient temperatures down to -18°C.
- All heaters and components are furnished with **weather-tight** enclosures.



## Prevention tip !

Ensure the thermostat set point is properly set to prevent unnecessary energy consumption.

The setpoint should be  $\pm 4^{\circ}$  C. Improper set points may result in year round operation of the heater package, even during summer time, causing increased energy consumption.

Want to benefit from a basin heater package? Contact your <u>local BAC</u> representative.

## **Downloads**

<u>The SERVICE EXPERT for BAC Equipment</u>