

Options and accessories

Pump relocation



Relocate the water recirculation pump **at the connection end** for fans encased with sound attenuators and improve inspection and maintenance access.

Want to relocate the pump on your cooling equipment? Contact your local [BAC representative](#) for more information.